


Tips For Cleaning Your Samsung Digital Signage

What do you need to clean and sanitize your Samsung digital signage?


- 1 Lint-free soft and dry cloths such as micro-fiber, superfine fibers or cotton flannels to prevent scratches
- 2 Water
- 3 99% pure Isopropyl Alcohol



How to clean your Samsung digital signage?


- 1  Disconnect the power plug
- 2  Using a soft dry cloth gently wipe away any finger prints and smudges on the screen and body with a soft and dry cloth to prevent scratches.
- 3  If dirt is still present, lightly spray a soft cloth with water. Always apply the water directly to the cloth, never on to the display and be sure to avoid getting any liquid in your display's openings.
- 4  Gently wipe display with dampened cloth
- 5  Wipe dry with a soft dry cloth

How to sanitize your Samsung digital signage*?

- 1  Disconnect the power plug
- 2  Apply a small amount of 99% pure Isopropyl alcohol (IPA) to a lint-free soft cloth .Always apply the IPA directly to your cloth, **never** on to the display and be sure to avoid getting any liquid in your display's openings.
- 3  Gently wipe the screen and body of the display to cleanse it.

*This sanitizing process is NOT applicable to any touch-screen type models including but not limited to: Flip, Flip2, PMF-BC, QBR-T, QBN-W, DME-BR, DME-BC, QB13R-T

Cautions!



Do not spray water or cleaner directly on the product

Do not spray water or any liquid directly onto the display. Any liquid that goes into the product may cause a failure, fire, or electric shock. This does not apply to Full Outdoor products(OH* series)

Prevent Scratches

The body and screen can get scratched during cleaning. Be sure to wipe the body and screen carefully using a soft cloth to prevent scratches.

Do not use general cleaners, compressed air sprays or disinfectant and bleach-based products, chemicals containing alcohol, solvent, or surfactant such as wax, benzene, thinner, pesticide, air freshener, lubricant, to clean the display . The product's exterior may be discolored or cracked, the surface of the panel may be peeled off, or the markings may be erased.

Learn More
Product Support
Follow Us

samsung.com/display samsung.com/business insights.samsung.com
1-866-SAM4BIZ
 youtube.com/samsungbizusa  @SamsungBizUSA