

# Guidance for Projector Cleaning/Disinfection



## **Basic information**

### **Outer case**

---

Wipe off dirt and dust with a soft, dry cloth.

- If the dirt is persistent, soak the cloth with water and wring it thoroughly before wiping. Dry off the projector with a dry cloth.
- Do not use benzene, thinner, or rubbing alcohol, other solvents, or household cleaners. Doing so may deteriorate the outer case.
- When using chemically treated dust cloths, follow the instructions written on its packaging.

### **Lens front surface**

---

Wipe off dirt and dust from the front surface of the lens with a soft clean cloth.

- Do not use a cloth that is fluffy, dusty, or soaked with oil/water.
- Since the lens is fragile, do not use excessive force when wiping the lens.



# Guidance for Projector Cleaning/Disinfection



## Q&A

**Q.** How should the Remote Control be cleaned (disinfected)?

**A.** It is recommended to use ethyl alcohol. Characters are directly printed on the remote control and buttons therefore there shouldn't be any issues.

**Q.** What disinfecting chemicals are recommended to clean the top covers of a Projector?

**A.** We recommend using ethyl alcohol. But please note that a cloth having too much alcohol may deteriorate the projector's cabinets.

**Q.** What is a good guidelines to use when cleaning the projector?

- A.** Wipe the projector with a soft cloth damped with a small amount of ethyl alcohol, then wiped the projector with a dry soft cloth.
- B.** Or just clean the projector with a dry soft cloth in the case that it is only needed to remove dust from the covers.

**Note:** Ethyl alcohol should be prevented from getting inside the projector.

